

## Instructions for smart timer management

All operation settings are required in power-off status



Off power status : Press "set" to entry 'Mode Select ' status;

Press + in 'Mode Select ' status to timer mode, Press - to cycle mode;

1、 In timer mode, press set to entry timer (minutes) set, Here the screen will display digital flashes, + will be minutes +, -will be minutes -, Setting range will be 000-999, When you set 000 as time,then the power sockets will be constant power mode, Press set again to exit setting status, Here the screen will display current timer time;

2、 In cycle mode,press set to entry cycle-digit selected status, Here the screen will display digital flashes, Press + or - to select cycle-digit as you want(for example 1~4 socket), When you select 3: Socket 1 ,2, 3,will be in cycle charging status, After you select cycle-digit ,then press set to select time(minutes) what you want to cycle on each socket, Press + or - to set cycle interval time, Setting range will be 000-999, Press set again to exit setting status.